



TELEFUNKEN | USA™

300 Pleasant Valley Road | Suite E | South Windsor, CT 06074
(860)882-5919 ph | (860)882-5980 fax | www.telefunkenusa.com

Congratulations!!

You have just purchased one of the finest recording instruments ever created, the Telefunken Ela M 260 small diaphragm tube microphone. Due to the sensitivity of the Ela M 260, there are specific handling and care instructions. Failure to adhere to them may void your warranty.

Handling and Care Instructions:

- Please be sure to secure the microphone to a stand or over-head boom before use.
- Please make all connections before turning power on.
- Let microphone warm up for at least 1 hour before each use.
- Do not inter-connect with historic/vintage microphones for any reason.
- We suggest the use of a pop screen for recording vocals.
- Be sure to turn off the microphone before disconnecting.

**Be conscious of your gain levels, this is a very sensitive recording instrument.
Damage may be done to the microphone.**

Ela M 260	SPECIFICATIONS
Type	Condenser Pressure Gradient
Capsule	M260, M261, M262
Polar Patterns	Cardioid, Omni, Hypercardioid
Frequency Response	20 - 20,000Hz
Tube Type	NOS Telefunken EF-732 Sub-Miniature
Sensitivity	14mV/Pa = -37dB (0dB = 1v/Pa) -10dB
Impedance	200 Ohms
S/N Ratio	79dB
Max SPL	120dB (for 1% THD @ 1000Hz)
Equivalent Noise	15dB (A weighted)
Power Requirement	Dedicated Power Supply
Controls	None
Dimensions	5 1/2" (140mm) length x 13/16" (21mm) diameter
Weight	4.2oz (119g)

Please contact us with any questions or concerns at contact@telefunkenusa.com or (860) 882-5919.

Thank you and once again Congratulations!!

All of us at Telefunken | USA